Language: English
Final size: 7.5cm x 8.5cm closed, 15.0cm x 8.5cm open
Format: 4 panel fanfold
Stock:
Ink:
Fonts supplied:
Film:
Author & coordinator:
Design & production:

Panel 2, Inside front cover

Fold

Panel 3, Inside back cover

WLAN 6120 and 6140 Handsets

For details on the features of these handsets, refer to the Nortel WLAN 6120 and 6140 Handset User Guide.

Safety information

Do not rely on a cordless handset in emergencies.

Never use your handset in:

- the vicinity of electrical detonators
- shielded rooms
- areas where radio transmission is forbidden
- aircraft

Do not place your handset near:

- water, moisture, or damp areas
- heat sources, direct sunlight, or unventilated areas
- devices that generate strong magnetic fields
- areas with excessive dust, shock, or temperature

Handset on	Press **End**
Handset off	Press **End**
Keypad lock	Press **Cfg** + **1**
Keypad unlock	Press **Cfg** + **Unlk**
Mute/Unmute	Press **FCN** + **Mute**
Terminating a call	Press **End**
Making an internal call	Press **Start**, wait for dial tone, dial extension
Making an external call	Press **Start**, wait for dial tone, dial number
Select a line	Press **Line**, number key corresponding to line
Dial a number	At dial tone, press phone number
Answering a call	Press **Start**, hold earpiece to your ear
Place a call on hold	Press **Fcn** + **Hold**
Answering a call on second line	Place first call on hold, press **Line**, then line #

Fold

Resume a held call	**Line**, line number key
Hang up	Press **End**
Adjust speaker volume	Press **Volume Up/Down**
Adjusting ring volume	Press **Volume Up/Down**
Mute while ringing	Press **End** to silence the ring
Activate/Deactivate speakerphone	Press **Spkr**
Display additional features	Press **Actv** to display features and available softkeys
Turn on backlight	Press any key
Change profile	**Nav keys** to scroll, **Enter** to select

Date: May 2007
Document Release: Standard 01.01
Document Number: NN43150-101
Copyright @ 2007 Nortel Networks. All Rights Reserved.
Nortel, the Nortel logo, and the Globemark are trademarks of Nortel Networks.
To provide feedback, or to report a problem in this document, go to:
www.nortel.com/documentfeedback

WLAN Handset 6120 and 6140
Quick Reference Card



NORTEL

Panel 4, back cover

Fold

Panel 1, front cover